

# MANNEQUIN HEAD & TORSO ASSEMBLY INSTRUCTIONS

## COMPONENTS



## STEP ONE

POSITION TORSO AND LINE UP WITH "CUT OUTS" IN BASE



## STEP TWO

TWIST TORSO 90 DEGREES IN EITHER DIRECTION TO LOCK INTO POSITION



## STEP THREE

SCREW WHITE BALL JOINT CONNECTOR TO TOP OF TORSO



## STEP FOUR

LINE UP HOLE IN BASE OF HEAD WITH TOP OF BALL JOINT CONNECTOR



## STEP FIVE

PLACE HEAD ON BALL JOINT CONNECTOR AND POSITION HEAD AS YOU WISH