

Push Rivet Instructions for Acrylic Displays

Plastic push rivets supplied with your display are easy to use and ensure a strong and durable stand.

The rivets have two positions: Open (fig.1) and Closed (fig.2).
The rivets must not be taken apart.



Align the holes on your display.

With the rivet in the Open position (fig.1), push it through both holes of the acrylic (fig.3).

You will hear an audible click when it is in the closed and locked position (fig.4).

Repeat as necessary.

